

Keyhole Piano TurnKey permanent placement hardware installation brief

We recommend all these procedures are completed for use in permanent placement situations.

Use 1-1/4" wood screws or equiv to fix the bottom 'sleds' to the lower lip.

Use a flat (mending) brace/bracket and 3/4" long wood screws to fix each side.

Use angle brackets and 1/2" wood screws to fix the top lid flap to the front section.

