


Keyhole Piano Shells

# Microphone Boom Arm

Use Manual



Remove the decorative plug from the end of the piano you wish to have your accessory post in.



Place the microphone boom post into the sleeve. It is now ready for use.

Note - microphone clip not included.

