

Keyhole Piano Shells

Clip-On Music Stand


Use Manual




Tuck the base under the upper lip.
The base can install anywhere along the
lip to your desired location.



Screw on base in the orientation shown.



Place the backboard into position.



Type B style placement

